



NOTE:

USE ONLY NATIVE SOIL FREE OF ROCKS AND CLODS FOR BACKFILL AROUND ANODES. PRE-PACKAGED ANODES SHALL HAVE 6" LIFT OF COMPACTED NATIVE BACKFILL. AFTER BACKFILL IS IN PLACE, SATURATE THE AREA WITH TEN (10) GALLONS MINIMUM OF WATER. AFTER ALL WATER HAS BEEN ABSORBED CONTINUE BACKFILLING.

APPROXIMATE PIPELINE STATIONING OF ANODE INSTALLATIONS		
DWG NO	STATION	ADDITIONAL WIRE

PRE-PACKAGED ANODE INSTALLATION DIRECTLY ON PIPELINE

NOT TO SCALE

PL12-13

031205

