

## NOTES:

- 1. WRAP ALL THREADS WITH TELFON TAPE.
- 2. COMPACT SOILS AROUND VALVE BOX TO 90% OF MAXIMUM DRY DENSITY.
- 3. FLUSH ALL MAINLINE PIPING PRIOR TO INSTALLING VALVES.
- 4. BOXES LOCATED IN PAVED OR VEHICLE TRAFFIC AREAS SHALL BE CONCRETE TRAFFIC BOX WITH METAL LID.

