



NOTE:

1. FURNISH FITTINGS AND PIPING NOMINALLY SIZED IDENTICAL TO NOMINAL QUICK COUPLING VALVE INLET SIZE.
2. WRAP ALL THREADS WITH TEFLON TAPE.
3. FLUSH ALL PIPING PRIOR TO INSTALLING VALVE BOX.

QUICK COUPLING VALVE ASSEMBLY DETAIL

NOT TO SCALE

LS-07

011107

