



NOTE:

COMPACT SUBGRADE TO 90% (EXCEPT AROUND PLANTS) AND APPLY A PRE-EMERGENT HERBICIDE TO THE SOIL BEFORE PLACING GRANITE AT REQUIRED DEPTH. RAKE SMOOTH, WET TO ENTIRE DEPTH, ROLL WITH A 150 LB. ROLLER, THEN LIGHTLY SCARIFY SURFACE WITH A LEAF RAKE. KEEP TOP OF GRANITE 1” BELOW ADJACENT WALKS, CURBS OR OTHER HARD SURFACES.

DECOMPOSED GRANITE INSTALLATION

NOT TO SCALE

LS-19

011207

