






GUIDE PLATE - DETAIL 1




STEM GUIDE - DETAIL 2



ELEVATION

VALVE OVERTORQUE PROTECTOR SEE SPECS. SEC. 33 10 02



HANDWHEEL OPERATING NUT - DETAIL 3

VALVE BOX ON VAULT DETAIL

NOT TO SCALE

PL05-7

030322

