



* WHEN PIPE LENGTH IS 2'-0" OR LESS THE RESTRAINED FLANGE ADAPTER INSTALLATION IS NOT REQUIRED. INSTALL CONTINUOUS PIPE FROM BALL VALVE TO 90° BEND.