



**NOTES:**

1. LIFT HANDLES AND DOWN RODS ARE TO BE MOUNTED ON THE EXTERIOR OF GATE (TYP).
2. WELD STEEL STOP BAR TO DOWN RODS AS REQUIRED TO PREVENT FULL REMOVAL

**DOWN ROD ASSEMBLY**

NOT TO SCALE

WE06-2

110309

