


NOTES:

1. CONNECT LOCAL CONTROL PANEL (LCP) TO GROUND GRID.
2. REFER TO DETAIL FOR CABINET MOUNTING.
3. REFER TO VAULT EXHAUST FAN CONTROL SCHEMATICS.



DESIGNER NOTE:
SEE DWG E10-1 AND E10-2 FOR DETAILS.

LOCAL CONTROL PANEL - DETAIL 1

VAULT PLAN

NOT TO SCALE

E06-1A

030922



FOR REFERENCE ONLY