


NOTES:

1. FOR ELECTRICAL ROUTING, SEE DETAIL 
2. WHEN POSSIBLE THE CONTROL TIMER SHALL BE INSTALL ON THE NORTH WALL, OUT/AWAY FROM THE SUN LIGHT.
3. USE ONLY FOR SITES WITH LESS THAN 6 STATIONS.

IRRIGATION CONTROL TIMER DETAIL

NOT TO SCALE

LS-11

071003

