


DESIGNER NOTE:
 REMOVE CAP AND MANUAL AIR RELEASE
 ASSEMBLY NOTE AND PORTION OF DETAIL
 WHEN NOT REQUIRED.



NOTES:

1. INSTALL VALVES CLOSED AND OPEN DURING TEST.
2. COAT AND WRAP OUTLET, VALVE AND PLUG. SEE SPECS SEC 33 05 13 AND 09 96 00.
3. OUTLET REINFORCEMENT SHALL BE DETERMINED PER AWWA M11 DESIGN METHOD.

VALVED OUTLET DETAIL

NOT TO SCALE

PL10-5 072715

