




CONDITION "A"




CONDITION "D"



CONDITION "B"




CONDITION "E"



CONDITION "C"

IF NO SIDEWALK, CURB AND GUTTER EXISTS, SET FIRE HYDRANT PAD ADJACENT TO R/W AS SHOWN IN CONDITION "D" ABOVE.

CONDITION F



CONDITION "G"

FIRE HYDRANT LOCATION

NOT TO SCALE

PL15-2 070703

