



NOTES:

1. MAKE ALL CONDUIT PENETRATIONS INTO THE BOTTOM OF THE RTU ENCLOSURE.
2. INSTRUMENTATION WIRING SHALL NOT BE RUN IN THE SAME CONDUIT AS 120VAC CONTROL WIRING.
3. THE RTU ENCLOSURE EXTERIOR FINISH SHALL BE POLYESTER URETHANE (POWDER COAT) WHITE.
4. ALL CONDUITS WITHIN TELEMETRY ENCLOSURE SHALL HAVE DIFFERENT COLORS PAINTED (3" MIN, BOTH INSIDE AND OUTSIDE). COLORS USED SHALL MATCH COLORS PAINTED INSIDE CONDUITS AT CONDUIT RISERS IN CONCRETE SLAB FOR CONDUIT ROUTE IDENTIFICATION (TYP).
5. DRILL SIX (6) 9/16" HOLES THROUGH ENCLOSURE/PEDESTAL AND INTO CONCRETE PAD. INSTALL ADHESIVE CARTRIDGES, 1/2" x 6" STAINLESS STEEL THREADED ANCHOR RODS WITH TWO (2) STAINLESS STEEL WASHERS AND LEVELING NUTS. INSTALL DRY PACK MORTAR IN ANNULAR SPACE AROUND ENCLOSURE/PEDESTAL AFTER ANCHOR RODS AND LEVELING NUTS ARE INSTALLED

PRV/FLOW STATION ENCLOSURE

IT01-4 111506

NOT TO SCALE

